

Collamat 9100

14 Password

In case of a lost password the firmware gives two procedures for recovery. One procedure uses the keyboard on the front panel. This procedure causes data loss. The other procedure uses a keyswitch but the monitor must be opened.

14.1 By keyboard

First switch power off. Then hold the **ENTER**-key while turning power on. The following message is displayed:

```
Clear memory !

Password      ####
Discontinue: [ESC]
```


Now type in **4148**. The Collamat will clear now the password to **0000**. The data of program number **32** will be set to default values and it will start up with program **32**.



NOTE:
This function is available since firmware 1.20.
Version 1.10....1.13 clears program 1.

If you type **4147** instead **ALL** programs are set to default values the password is also cleared and program **1** is selected.
This procedure is also helpfull to restart a completely misprogrammed Monitor which hangs after power on.

14.2 By keyswitch



Danger:
Before opening the monitor unplug the mains plug. Charged capacitors inside the monitor may lead to shock hazard. After unplugging wait at least 10 seconds before opening the monitor.

For this procedure the monitor must be opened. On the interfaceprint (see figure 38) two jumpers J1 and X9 must be set. Now after power on in the **Configuration** menu **User level** the password can be changed.

Monitor

RESET